



# Ubiquiti UAP PRO Teardown

Here is a Teardown for a Ubiquiti UAP PRO (not AC)

Written By: rafael51





## Step 1 — Ubiquiti UAP PRO Teardown



- Remove 4 x T15 Screws

## Step 2



- Insert wisdom here.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-18 06:58:08 PM.

